AOR SR2200 OPERATING MANUAL

HIGH-END BLACK-BOX RECEIVER

	azhil
25 MHz- 3 GHz High frequency stability +/- 1ppm High sensitivity & selectivity	ANT
PC control by USB or serial port Discriminator OUT	end Go
10.7 MHz I.F. OUT	
	80\$
	S
	REMOTE
AOR SR2200	Sec.
	EXT.SP
	HONES

ñ



Safety notices

Every effort has been made to make this manual correct and up to date. Due to continuous development of the product and by error or omission, anomalies may be found and this is acknowledged.

© This manual is protected by copyright AOR Ltd 2013. No information contained in this manual may be copied or transferred by any means without the prior written consent of AOR Ltd. AOR and the AOR logo are trade-marks of AOR Ltd. All other trade marks and names are acknowledged. E&OE

Level of risk

As the SR2200 is powered from 12V DC, there is little chance of serious injury as long as common sense is applied.

DC input is a nominal 12V DC wired center positive. Reverse polarity connection will damage the SR2200 and potentially could lead to the risk of fire or explosion under severe circumstances.

NEVER connect the SR2200 directly to an AC outlet.

Handling the SR2200

Use a soft, dry cloth to gently wipe the SR2200 clean, never use abrasive cleaners or organic solvents which may damage certain parts. Treat the unit with care, avoid spillage or leakage of liquids into the cabinet. Special care should be taken to avoid liquid entering via the connection sockets.

Special remarks

Do not use or leave the SR2200 in direct sunlight. It is best to avoid locations where excessive heat, humidity, dust and vibration are expected. Always keep the SR2200 free from dust and moisture.

Other warnings

There are no internal operator adjustments. In the unlikely event of servicing being required, please contact your dealer for technical assistance.

Although carefully designed, the SR2200 (like all receivers) suffers from a degree of internal noises known as spurii. They are a product of the receiver circuitry and do not represent a fault. The reception might be affected by interferences produced by nearby electrical appliances such as television, PC, walkie-talkies, etc... The reception might be strongly affected by powerful transmissions if the receiver or the antenna is located nearby a transmitter (such as TV broadcasting transmitter).

Transmissions with encrypted content cannot be decoded by this receiver.

Specification is typical but not guaranteed, subject to change without notice due to continuous development of the product.

TECHNICAL SPECIFICATIONS

Configuration	Triple conversion superheterodyne				
Frequency coverage	25MHz - 3GHz	25MHz - 3GHz			
Reception modes	AM / NFM / WFM	AM / NFM / WFM / SFM			
Sensitivity	Band	Sensitivity	IP3 (dBm)	S/N (dB)	
IP3	25M-225MHz	NFM: 0.35uV (12dB SINAD)	1	40	
S/N		AM: 0.6uV (10dB S/N)			
		WFM: 2.0uV (12dB SINAD)			
	225M-1.7GHz	NFM: 0.35uV (12dB SINAD)	1	35	
		AM: 0.8 uV (10dB S/N)			
		WFM: 2.0uV (12dB SINAD)			
	1.7GHz -2.7GHz	NFM: 0.6uV (12dB SINAD)	1	32	
	2.7GHz-3GHz	NFM: 1.5uV (12dB SINAD)	1	30	
IF frequencies	1st IF: 255.3MHz,	744.3MHz			
	2nd IF: 10.7MHz				
	3rd IF: 455kHz				
Tuning steps	100 Hz to 100 kHz (10 Hz incremental)				
Selectivity	NFM: +/-10kHz, 60dB				
	AM/SFM: +/-6kHz, 60dB				
	WFM: +/-180KHz, 60dB				
Spurious Sensitivity	60dB>	60dB>			
Adjacent Selectivity	55dB >				
Dynamic Range	90dB>				
Unwanted Spurious emissions	< -57dBm				
IP3	+1.0 dBm				
Frequency stability	+/-1ppm (0-50°C)				
Audio output	1.2W (8Ω) max.@ 10% distortion (no internal speaker!)				
Power requirements	12 - 16V DC, 0.5 A with 1W audio output				
Aerial connection	50 Ω BNC				
IF output	10.7MHz				
Control interface	RS-232C / USB ,	38400bps			
Operation temperature	0 to 50°C				
Dimensions	200(W) x 31(H) x	230(D) mm, without projections	•		
Weight	1.23kg				
Nominal filter bandwidths	6kHz, 15kHz, 300	kHz.			
Memory channels	1000 (10 banks)				
Search banks	40				
Scan/Search Rate	25 steps per seco	nd.			
Pass frequencies	2000				
Priority channels	1				

SUPPLIED ACCESSORIES

- DC power cable
- Operating manual
- Basic control software for testing purposes, on CD. This software does not support USB connections, only RS-232C. If your PC (particularly laptops) does not feature a RS232C port, you may alternatively use a "USB to SERIAL" adapter. <u>This software is supplied "as is" without any guarantee of any kind.</u>
- Complete command list (inside the manual)
- USB driver on CD.

CONNECTIONS

Refer to this diagram for connection details:



- ① 10.7MHz IF OUT with +/- 5MHz of bandwidth.
- 2 Headphone socket (3.5mm mono jack, also wired for stereo plug). When this socket is used, any external speaker connected to socket (3) will be automatically disconnected.
- (3) External speaker socket (3.5mm mono). The speaker should have a nominal 8 Ω impedance and power handling of 2 Watts or greater.
- ④ Accessory socket. Provides output for audio and discriminator, or other applications you might create. Pin allocation as follows:



PIN NUMBER	CONNECTION			
1	6V DC @ 30mA max.			
2	Discriminator out, 500mVp-p			
3	10.7MHz IF (no amp, no filter)			
4	No connection			
5	No connection			
6	AF out (H), 120mV @ 600 Ω			
7	AF out (L), 60mV @ 600 Ω			
8	Ground			

Values for pins 2, 6, 7 are for a 3kHz FM deviation at antenna input level.

- ⑤ RS-232C socket for PC control. The connection cable is not supplied..
- (6) USB socket for PC control. The connection cable is not supplied.

When you connect the SR2200 (power ON) to the PC for the first time, Windows will detect the USB connection and ask you for a driver. At this time insert the supplied CD and find the folder named "USB DRIVER". Driver installation will be automatic.

Please note that the supplied SR2200 control software does not function with a USB connection. You may use the Windows "Hyper Terminal" software which is supporting USB connections.

- ⑦ 12V DC input socket. The DC power cable is supplied. Please connect it to a power unit providing 12 to 16V DC, with minimum 0.5 A. Center pin is positive.
- 8 Power switch and power LED. Unit is powered and the green LED is lit, when the switch is in the upper position.
- (9) Antenna socket. BNC type. Preferably use an antenna with coaxial lead matched to 50Ω , for optimal performance.
- ① Remote control panel. The <u>optional</u> control panel head (with internal speaker), similar to the control panel of AR-ONE is used to test functionality of the receiver, when a PC is not available.

CONTROL COMMANDS FOR TERMINAL SOFTWARE

The SR2200 is operated via PC using the RS232C, or USB port. The commands necessary to that effect, are described in this chapter.

Microsoft Windows Hyper Terminal may be used to control the SR2200, or you may use your own software by integrating the following commands.

Communication parameters

- Baud rate 38400 BPS
- Data length 8 bits ^A nn [cr],[LF] ... ^A = 13 Hex ... nn = Receiver's ID #
- Stop bit 1 bits If ID # = 00 (DEFAULT VALUE), command can be input directly.
- Parity NONE
- Flow control NONE
- Local echo
 ON (set in ASCII settings of Microsoft HYPERTERMINAL)

Delimiter

```
■PC \rightarrow SR2200
<CR> (0x0d)
or
<CR><LF> (0x0d 0x0a)
Note: <LF> will be ignored
```

- $\blacksquare SR2200 \rightarrow PC$
 - "OK" response when the command has been correct: <SP><CR><LF> (0x20 0x0d 0x0a)
 - Response when the command has been incorrect: ? <CR><LF> (0x3f 0x0d 0x0a)
 - Response to the read command: Following the output of the parameter, the correct response should read: <SP><CR><LF> (0x20 0x0d 0x0a)

Numerical parameter auto-correct

The SR2200 does correct the numerical command parameter to the digit format applying to the given parameter. In the following example, the DB command has to be followed by a 3-digit number.

Ex.: DB003 <CR>

The SR2200 will add one or two "0" in order to achieve three digits.

DB3<CR> processed as DB003<CR> DB03<CR> processed as DB003<CR>

However be aware that for some commands like Memory Channel or Search Bank, if you input MQ33 for MQ303 (bank 3, channel 3), the SR2000 would mistakenly correct your entry to MQ033 which means bank 0, channel 33.

COMMAND LIST

COMMAND NAME	REQUEST CMD		COMMAND DESCRIPTION
	CMD or HEADER	R/W	
- POWER ON	x	W	When the receiver's power is off, any key will power it on.
- POWER OFF	QP	W	POWER-OFF the receiver
- REMOTE ON	^Ann	W	<pre>^Ann nn = ID # means control unit A with ID # = 00 to 99 (Note) In case ID # = 00 (DEFAULT VALUE),the</pre>
			command can be input directly.
- REMOTE OFF	EX	VV	Stop control of remote receiver
- ID (REMOTE)	IDnn	W	nn = 00 - 99 (Setting an ID to the remote receiver)
		R	IDnn
- Rx-MODE	Vx	W	VFO selection. x = A - J(DEFAULT is VFO-A)
	MRmnn		Memory Read. m = BANK # from 0 - 9 and n = CH # from 00 - 99.
	MSm		Memory Scan. m = BANK # from 0 - 9
	SM		Memory Select
	SSmm		Normal Search. mm = BANK # from 01 - 40
	RX	R	RFU STATUS
			MR MXmnn RFnnnnnnnnn STnnnnnn AUn MDn BWn ATn AMn TMxxxxxxx
			MS MXmnn RFnnnnnnnnn STnnnnnn AUn MDn BWn ATn AMn TMxxxxxxx
			SM MXmnn RFnnnnnnnnn STnnnnnn AUn MDn BWn ATn AMn TMxxxxxxx
			SSmm RFnnnnnnnnn STnnnnnn AUn MDn BWn ATn AMn TTxxxxxxx
			Vx RFnnnnnnnnn STnnnnn AUn MDn BWn ATn
			(Priority Channel) PPmnn RFnnnnnnnnn STnnnnn AUn MDn BWn ATn AMn TMxxxxxxx
- FREQUENCY	RFnnnnnnnn	W	Active VFO's Frequency in Hz.
	RFnn.nn		Active VFO's Frequency in MHz
	RFnnn		Active VFO's Frequency in MHz
	Vx		Vx nnnnnnnnn (Hz) VFO selection followed by

			frequency in Hz.
	RF	R	Active VFO's Frequency. RFnnnnnnnnnn (Hz)
- FREQ STEP	STnnnnn	W	Frequency STEP in Hz. Not valid for Search. (AUTO MODE will be set to off)
	STnn.nn		Frequency STEP in KHz.
	STnn	<u> </u>	Frequency STEP in KHz.
	ST	R	Frequency STEP in Hz. STnnnnnn (Hz)
- RECEPTION MODE	MDn	W	n = 0 NFM (BW = 15 K)
			n = 1 WFM (BW = 300 K)
			n = 2 AM (BW = 6 K)
			n = 3 SFM (BW = 6 K)
			n = 4 WAM (BW = 15 K)
	MD	R	MDn
- AGC	AC n	W	n = 0 AGC-OFF
			n = 1 AGC-FAST
			n = 2 AGC-SLOW
			n = 3 AGC-MIDDLE
	AC	R	ACn
- RF-ATTENUATOR	ATn	W	n = 0 00 dB
			n = 1 10 dB
			n = 2 20 dB
			n = 3 AUTO (Depending on the signal level,
		 	RF-AMP will automatically change to on or off)
	AT	R	ATn (n = 3 AUTO ATT/AMP)
- RF-AMP	AMn	W	n = 0 RF-AMP OFF
			n = 1 RF-AMP ON
			$n = 2 \dots AUTO$ (Depending on the signal level, ATT
		R	$\Delta mn (n = 3 \Delta I ITO \Delta TT / \Delta MP)$
- NOISE-SOUELCH	ROnn		ROnnn = 000 - 255
	r comm		This command can be applied to VFO. MEMORY
THRESHOLD			and SEARCH DATA
			When the optional Remote Control Panel is
			connected, the AF-volume must be turned to
		<u> </u>	minimum for the command to function.
	RQ	R	RQ nnn

- LEVEL-SQUELCH	DBnnn	W	DBnnn nnn = 000 - 255 (Default is 000 for off)
			This command can be applied to VFO, MEMORY
THRESHOLD			and SEARCH DATA
			When the optional Remote Control Panel is
			connected, the AF-volume must be turned to
			minimum for the command to function.
	DB	R	DB nnn
- AF-GAIN	AGnnn	W	AGnnn nnn = 000 - 255 (Default is 255)
			When the optional Remote Control Panel is
			connected, the AF-volume must be turned to
			minimum for the command to function.
	AG	R	AG nnn
- MANUAL-GAIN	MGnnn	W	MGnnn nnn = 000 - 255 (Default is 255)
			AGC must be set to OFF.
	MG	R	MG nnn
- SELECT SQUELCH	SQn	W	n = 0 NOISE-SQ (DEFAULT)
			n = 1 … LEVEL-SQ
	SQ	R	SQn
		D	ATn AMn NSQm LMnnn When NOISE-SQ is
			selected (nnn = 000 - 999)
			ATn AMn LSQm LMnnn When LEVEL-SQ is
			selected (nnn = 000 - 999)
			m = 0 SQUELCH closed
			m = 1 SQUELCH open
- AUTO SIGNAL	LCn	W	n = 0 OFF
			n = 1 … ON (When the squelch opens, signal
		_	level and frequency are returned)
	LC	R	LCn
		R	SQm LCnnn RFnnnnnnnnn
			m = 0 When NOISE-SQ is selected.
- SCAN/SFARCH	SGn	W	When scan/search is in operation: when it stops,
			the squelch opens and closes again. Then
RE-START CMD			scan/search resumes . This SG command repeats
			the process.
			n = 0 NO-OPERATION
		<u></u>	n = 1 … Re-starts [SG]
	SG	R	SGn

- DELAY-TIME	DD	W	DD n.n n.n = 0.0 - 9.9 sec (DEFAULT = 2.0
			sec)
			Delay before shifting to next channel.
			nn = FF HOLD
	DD	R	DDn.n or DDFF
- FREE SCAN	SP	W	SPnn n.n = 0.0 - 9.9 sec (decimal can be omitted)
			n.n = 0.0 FREE-SCAN OFF (DEFAULT)
			= 0.1 - 9.9 sec
	SP	R	SPn.n
- SELECT S-METER	SF	W	n = 0 … DIGTAL METER … dBuV (DEFAULT)
			n = 1 … DIGTAL METER … dBm
		R	SFn
- DUPLEX ON/OFF	OFnnx	W	OFnnx nn = 00 - 47 (00 = OFF)
			x = + or -
	OF	R	OF xnn
- DUPLEX FREQ	OLmm nnnn	W	OLmm nnnnnnn00 mm = 01 - 19
SETTING			nnnn n = FREQ-DATA (up to 1000 MHz, 100
			Hz step)
	OLmm	R	OLmm nnnnnnnn
	OL		OLmm nnnnnnnn
- INTERVAL TIME	ABnn		ABnn nn = 02 - F0
OF AUTO ATT/AMP			nn = 02 APPROX 100 ms
			nn = 03 150
			nn = 08 350
			nn = 0B 500 (DEFAULT)
			nn = 10 700
			nn = 30 2000
			nn = F0
	AB		ABnn
- S-METER LEVEL	LU	R	LU S-METER LEVEL (dBuV)
(dBuV)			LU nnnnn ~ nnn
- S-METER LEVEL	LB	R	LB S-METER LEVEL (dBm)
(dBm)			LB nnnnnn ~ nnn
- S-METER GAIN	KKnn	W	KKnn nn = 00 - 99 (1.00 - 1.99)
(constant)	КК	R	KK nn

- SEARCH DATA	SEnn	W	SEnn nn = 01 - 40 BANK #
			SLnnnnnnnnn (START-FREQ) Refer to RF
			command
			SUnnnnnnnnn (STOP-FREQ) Refer to
			RF command
			AUn Refer to AU command
			STnnnnn, MDn, BWn, ENn, ATn, AMn, AC n
			Separate commands with one blank space.
			TTxxxxxxxx (TITLE) Use if necessary.
			Spaces are OK.
- SEARCH DATA LIST	SRnn	R	SR CURRENT BANK'S SEARCH-DATA
			(Format as below)
(settings)			SRnn nn = 01 - 40 Search data of specific
			search bank (Format as below)
			SRn n = 1 - 4 Search data in one of the 10
			memory channel banks.
			(1-bank + t0 +0, 2-++ t0 20, 3-2+ t0 30, 4-3+ t0
			SP%% Search data of all banks
		R	
			SDn (BLANK)
			DW/ Make the surrent frequency a DASS
- PASS-FREQ	PW	W	Frequency
			PWnnnnnnnn Manually input a pass
			frequency.
- PASS-FREQ LIST	PR	R	PRnn nn = 01 - 40 (BANK #)
			There are 50 frequencies in each of the 40 banks,
			total 2000 frequencies.
			PR00 nnnnnnnn
			PR01 nnnnnnnn
			 DDmm
- DELETE PASS-FREQ	PD	W	PUMMNN $MM = 01 - 40 (BANK #) / nn = 00 - 40 (BANK #) / nn = 00 - 40 (BASS CH #)$
			a appoint bank are deleted
			$PDmm\%\% \dots mm = 01 - 40 (BANK #) \dots All$
			pass inequencies from a given ballk are deleted. OSph. $ph = 01 - 40$ The search data and pass
- DELETE SRCH DATA	QSnn	W	frequencies inside a given bank will be deleted
I		l	הטקעטרוטוט ווווועט א פויצרו אמווג שווו אם עבובנבע.

			QS%% The search data and pass frequencies of
WITH PASS-FREQ			ALL banks will be deleted.
- COPY TO VFO	SV	w	SVn n = 0 - 9 (VFO-A - VFO-J) Copy the
			current search data to VFO.
			n = 0 VFO-A
			: :
			n=9…VFO-J(DEFAULT 時、VFO-J へ)
- MEM DATA SETTINGS	MX	w	MXmnn Write CURRENT RX-DATA to BANK # = m, CH # = nn
			MXmnn m = 0 - 9 BANK # / nn = 00 - 99
			RFnnnnnnnn (FREQUENCY) Refer to RF command.
			AUn Refer to AU command.
			STnnnnn, MDn, BWn, ENn, ATn, AMn, AC n
			Separate each command with a space.
			GAn (GA M-SEL ON/OFF) Separate
			each command with a space.
			IMXXXXXXXX (IIILE) Use if necessary.
	ΜΔ	P	MAm $m = 0 - 9$ (BANK #) (Format as below)
	MA		MAmpn = 0 - 9 (BANK #) (romat as below)
			#) Only for the specified memory channel.
			MXmnn MPn Gan RFnnnnnnnnn AUn MDn BWn
			ATn AMn TMxxxxxxx
			MXmnn
- MEMORY SELECT	GA	W	n = 0 OFF
ON/OFF			n = 1 ON
	GA	R	GAn
- SEL MEM LISTING	GR	R	GRnn nn = 00 - 99 (Display of specified memory channel)
			GR%% ALL-CH (MAX 100-CH)
			GRn $n = 0 - 9$ (10 channels are set and
			displayed)
			GR List up content of all 10 channels
			GRnn mxx nn = CH # / m = MEM-BANK # / xx = MEM-CH #
- DELETE MEM	MQn	W	MQn n = 0 - 9 (BANK #)
			MQ%% ALL-BANK
- MOVE TO VFO	MV	W	MVn n = 0 - 9 (VFO-A - VFO-J) Apply the

			current memory data to VFO.
			n = 0 VFO-A
			: :
			n = 8 VFO-I (DEFAULT)
			n = 9 VFO-J
- MEM-CH READ	MRmnn	W	MR READ CURRENT MEMORY DATA
			MRmnn m = 0 - 9 BANK # / nn = 00 - 99
			CH #
- MEMO WRITE	MW	w	MW To save the data of the frequency currently being received. Automatic memory channel allocation.
- MEMORY BLANK	MB	R	MBm m = 0 - 9 (BANK #)
			Searches for available channels in a bank.
CHANNEL LIST			Channels are displayed by groups of 10, delimited
			Dy [].
			PPmnn $m = 0 - 9$ BANK #/nn = 00 - 99
- SELECT PRIO-CH	PPmnn	W	CH #
	PP	R	PPmnn RFnnnnnnnnn (NORMAL) or RF
			(BLANK)
- INTERVAL TIME	TInn	W	TInn nn = 01 - 20 sec (DEFAULT = 05 sec)
OF PRIORITY	ТІ	R	Tinn
- PRIO ON/OFF	PQn	W	PQn n = 0 or 1
			n = 0 OFF PRIORITY OPERATION
		L	n = 1 ON PRIORITY OPERATION
	PQ	R	PQn n = 0 or 1
- LEVEL WAIT	LTnn	W	LTnn nn = 01 - 95
			- Time during which the level is put on hold until it
			stabilizes.
			n = 1 APPROX 1 ms
	LTnn	R	
- DISPLAY FLASH	DMnnnn	R	DMmmmm mmmm = 0000 - FFFF (ROM ADDRESS) Last of 4 digits must be "F"
			DMmmmF:nn nn nn 16 bytes per line, 8
MEMORY			lines.
			(Space command allows view of following ROM
			address)
- EDIT FLASH-	CM [SPACE]	W	(ROM-ADDRESS)

MEMORY DATA			mmmF:nn nn nn (To display the original 16 byte data)
			mmmF: xx xx (enter data instead of xx,
			separate with blank space)
			CMA00F 5A C3 5A C3 ==>Changed to
			00 00, Flash memory is initialized with [RESET] or
			[PWR-ON].
- MODIFY FLASH	MM	W	MMmmmF nn nn nn nn nn (At the address mmmF, 16-BYTE DATA is input)
MEMORY			
- PLL UNLOCK	LW	W	LWnn nn = 02 - 20 ms (DEFAULT = 02)
WAIT-TIMF			(Time setting for PLL lock after frequency change.
			Wrong timing might create PLL errors.)
	LW	R	LWnn
- SQ WAIT-TIME	SW	W	SWnn nn = 00 - 50 ms (DEFAULT = 10)
		<u></u>	Signal squelch check time after the PLL is locked.
	SW	R	SWnn
- BIRDIE CANCELI	Pl n	W	Shifting the PLL data from the current reception
	1 211	•••	frequency.
REQUEST			n = 0 OFF
			n = 1 +200K
			n = 2200K
	PL	R	PLn
- MAIN VERSION #	VR	R	VR MAIN VERSION #
			VR yyyy-mm-dd
- VFO DEFAULT	CL [cr]	W	CLReset the VFO to default.
- RESET	RS [cr]	w	Flash ROM is re-initialized, after switching the
	- L- J		receiver off and on again.
			(SRCH-DATA and MEM-DATA will be lost!)
- SERIAL #	SNnnnnnnnnn	W	SNnnnnnnnnn … nnnnnnnnn … SERIAL # (10 digits)
	SN [cr]	R	SNnnnnnnn

USING THE SUPPLIED "SR2200 CONTROL SOFTWARE"

<u>The software is supplied "as is" for testing purposes, with no warranty nor formal support.</u> <u>The "SR2200 CONTROL SOFTWARE" only recognizes the receiver's RS232C connector.</u> <u>If your PC (particularly laptops) does not feature a RS232C port, you may alternatively use a</u> <u>"USB to SERIAL" adapter.</u>

System requirements:

- IBM PC compatible receiver with an available RS232C port.
- Microsoft® Windows® 98 up to Vista (32 bit). 64bit systems not supported.
- Pentium® 300MHz processor or faster
- RAM and hard disk space requirements are negligible.
- ① **Connect the SR2200 to your PC using a serial cable.** Make sure that you have powered on the SR2200.

In case you would like to use a "USB to serial" adapter, install this adapter first as specified by the manufacturer's instructions.

② Install and launch the control software. The main control window looks like this:

🗊 SR2200 Control Software	
View(V) COM(C)	
Receiver Mode VFO C MEM C M.SCAN C M.SEL C SEARCH	MODE: WFM STEP : 100.0k STEP : S Meter (Realtime display) RF Amp auto C 10db C 20db C 20db C 20db C 20db
81.300000 < >	
VOLUME 002	SQUELCH UUU Opend

The default COM PORT 1 setting should allow you to control your receiver right away. Depending on you PC's configuration, the COM PORT to which you connected the SR2200 can be different from COM1. In this case it is necessary to select the appropriate number as pictured on the right.

🖉 SR2200 Control	Software		
View(V) COM(<u>C</u>)			
Recei Port(P) C VFO C MEM C M.SCAN VFO C M.SEL C SEARCH 81.30	COM 1(1) COM 2(2) COM 3(3) npu COM 4(4) COM 5(5) COM 6(6) COM 7(7) COM 8(8)	t MODE: WFM ▼ auto STEP: 100.0k ▼ ON	ATT auto C 0db C 10db C 20db
		Subject out opena	•

When using a "USB to serial" adapter, the COM number Windows automatically assigns can be quite high, such as 5 to 8. You will need to select the correct COM port, as pictured. It is possible that you then may have to close the program and to start it again, for the connection to be recognized.

Please make sure that the RS232C port speed is set at 38400 bps and not 19200 bps, otherwise the connection with the PC will fail. Access this option by selecting **COM > Speed** and then select "38400 bps".

HOW TO INPUT A FREQUENCY

① First select the VFO (VFO A to J) in which the frequency will be stored. If the VFO already contains a frequency, then the receiver will be tuned to it.

🗊 SR2200 Control Software		×
View(V) COM(C) Receiver Mode G VFO C MEM C M.SCIN C M.SCIN C M.SEL C SEARCO	MODE: WFM STEP: 100.0k STEP: 100.0k MODE: WFM STEP: 100.0k MODE: WFM STEP: 100.0k MODE: WFM MODE:	
81.300000 < >	SQUELCH 000 Opend	
	Noise C Level	

② Click the "Freq.Input" button:

ntrol SR2200 Control S	oftware	
View(⊻) COM(<u>C</u>)		
Receiver Mode C VFO C MEM C M.SCAN C M.SEL C SEARCH	A Freq. Input MODE: WFM	
81.300	000 < >	
VOLUME-002		ise C Level

The following window will appear:

🗊 FormFreq			
Freq. 104.1	C Hz C KHz <=	104.1 MHz 101.2 MHz 99.5 MHz 81.3 MHz 90 MHz	
🗸 ок	X Cancel	All Clear	Delete

③ Input the desired frequency in the left frame and click OK. If other frequencies have been stored previously in other VFO's, you may select one in the right window, transfer it to the left window by clicking on the <= arrow, and validate with OK.

View(V) COM(C)			
Receiver Mode VFO MEM M.SCAN C.M.SEL C.M.SEL C.M.SEL	MODE: WFM STEP : 100.0k		All auto Odb C 10db C 20db
81.300000 <	> S Meter	r (Realtime display)	
VOLUME 002		se C Level	•

OTHER FUNCTIONS

 Reception Modes: You have to manually choose between: AM (Amplitude Modulation). IF filter bandwidth of 6 kHz.
 NFM (Narrow Band Frequency Modulation): IF filter bandwidth of 15kHz.
 WFM (Wide Band Frequency Modulation): IF filter bandwidth of 15kHz.
 SFM (Super Narrow Frequency Modulation): IF filter bandwidth of 6kHz.

- ② Frequency Step size: You have to manually choose between 0.1, 0.5, 1, 2, 5, 6.25, 9, 10, 12.5, 20, 25, 30, 50, and 100kHz.
- ③ **RF Preamplifier:** Select either "auto", "ON" or no selection for disabling the preamplifier.
- ④ **RF Attenuator:** Select either "auto", "0dB", "10"dB, or "20dB" of attenuation.
- 5 **Signal Strength Meter**: It is for relative signal strength comparison and calibration may not be totally reliable.
- ⑥ Squelch Control: There are 2 types supported, NOISE squelch and (signal) LEVEL squelch. Move the slide to the right (for values from 0 to 255) until the unwanted noise disappears.
- ⑦ Manual Frequency Tuning: Using the left arrow (for tuning down) or the right arrow (for tuning up) you can decrease or increase the frequency by the value defined in the (2) Frequency Step section. For finer tuning, use lower STEP values.
- 8 **Volume Control**: Represents the AF audio output through the external speaker & headphones sockets. The SR2200 has no internal speaker!

Volume scale is from 000 to 255. Beware of excessive volume level when using headphones.

9 Functions not supported.

TERMINAL-THE COMMAND WINDOW

Access the Terminal window through the VIEW menu.

SR2200 Control Software	e		
Terminal(T) C MEM C MEM C M.SCAN C M.SCAN C M.SEL C SEARCH	Freq. Input	MODE: WFM STEP: 100.0k STEP: 100.0k STEP: 100.0k	ATT auto C 0db C 10db C 20db
81.300000	< >	S Meter (Realtime display)	
VOLUME-002		SQUELCH 000 Opend	•

This window allows you to monitor the data flow from SR2200 to the PC, and to check upon the SR2200 data response when a Command Instruction has been entered.

🗊 SR2200 Terminal	
Clear(C) V Newest line RadioGroup1 • Normal C Details C Debug	Command(0) CommandListClear (Delete)
[U5/10/06 16:28:58] [rx]ATD AH1 NS01 LH596 [U5/10/06 16:28:59] [rx]ATD AH1 NS01 LH597 [U5/10/06 16:29:00] [rx]ATD AH1 NS01 LH599 [U5/10/06 16:29:00] [rx]ATD AH1 NS01 LH599	~
105/10/06 16:29:00] [rx]ATD AH1 NSQ1 LH602	

Memo

AOR, LTD. 2-6-4, Misuji, Taito-Ku Tokyo, 111-0055, Japan URL: www.aorja.com

US distributor:

AOR USA, INC. 20655 S. Western Ave. Suite 112 Torrance, CA 90501 Phone: 310-787-8615 Fax: 310-787-8619 URL: www.aorusa.com e-mail: info@aorusa.com

Dec.26, 2013

Printed in Japan